

Straightness & Parallelism




Contents

- Straightness Measurement
 - Reference Types
 - Analysis
 - Filter Selection
 - Gaussian Filter Characteristics
- Straightness on Narrow Components
- Parallelism
 - PAR Definition
 - PAR (D) Definition
- Summary

Global Excellence in Metrology








Instruments with vertical straightness units can be used to measure vertical straightness.

The movement of the stylus is controlled in a linear manner, the vertical and radial displacements can be recorded and analysed as a straightness measurement.

Prior to measurement the component should be centred and levelled with respect to the spindle axis to reduce any tilt errors which may affect the straightness result. This is of particular importance when measuring long, and/or small diameter components.


If the instrument is fitted with a Radial Straightness Unit (RSU) horizontal straightness is also possible. Prior to measurement it is important, in this instance, to ensure that the component surface is levelled and square to the spindle axis.



The above slide shows the two reference types used for the analysis of Vertical and Horizontal straightness.


The least squares reference line is fitted to the raw measured data such that the sum of the squares of the deviations of the profile are minimised. The straightness value is the maximum peak to valley deviation perpendicular to the LS line.

The minimum zone reference is the minimum separation of two parallel lines which totally enclose the data and are of minimum separation. The straightness value is the separation of the two minimum zone lines.



The computerised method for the analysis straightness is as follows;

- The raw data is shown relative to the instrument vertical straightness unit (column). This data will have a certain amount of tilt, depending how well the component has been centred and levelled.
- An MZ or LS reference is fitted to the raw data to remove the tilt from the measured data.
- The resultant profile is then passed through a filter which attenuates wavelengths shorter than the selected cut-off value.
- From this modified profile the straightness parameters can be calculated.




The default cut-off selection for a straightness analysis as recommended in ISO 12781-2 is a Gaussian 0.8mm. This applies for measurement lengths greater than and including 4mm.

The table shown above applies for lengths shorter than 4mm.

*METEK


In reality the selected cut-off value would depend upon the information required from the surface and what influence certain wavelengths would have on the component's performance.



The characteristics for a Gaussian straightness filter are shown in the graph above.


The amplitude of Wavelengths at the selected cut-off value are attenuated by 50%. This attenuation is progressively greater towards the shorter wavelengths.

In other words the amplitudes of the shorter wavelengths will be attenuated leaving the longer wavelengths for inclusion in the straightness analysis.




As can be seen from the above slide the choice of filter value will have quite a significant effect on the STRt value.

This illustrates the importance of selecting a cut-off value which is suitable for the length and function of the part being measured. Also to prevent any misunderstanding between supply and customer in the interpretation of straightness results.



When measuring straightness of narrow components it is difficult to keep the stylus on the crest of the part.


For example if straightness is required on the above part and the part is leaning problems will appear in the measurement.



Here is a view of a cylinder that is tilted in the none measuring direction.

As the stylus is tracked up the cylinder it will pass around the crest of the part and produce a straightness track similar to that shown on the right hand side of the above picture.


This result will show a combination of both straightness error and the deflection of the stylus around the crest of the component.



To prevent this phenomena a bar stylus can be used.

This stylus consists of a cylinder fixed to a stylus arm and set perpendicular to the stylus arm.


A side view of the stylus shows it as a standard stylus with a standard radius when used in the measuring direction.



Because of the width of this stylus, cresting errors will be reduced when measuring straightness.


This sort of stylus is also useful for measuring straightness of extremely thin edges such as rubber blades for screen printing.

It can also be used for roundness measurement where high frequency elements of the surface are less critical, the bar will prevent cresting errors.




If the column or vertical straightness unit of the measuring system is parallel to its spindle axis then other relationships can be established when analysing straightness.

In the case shown here it is possible to measure a cylinder and construct an axis, parallelism of the straightness track can then be analysed with respect to this axis.




By measuring two sides of a cylinder it is possible to find the parallelism of the cylinder.

The bi-sector of the two straightness tracks can also be used for further analysis to other measured features.



A datum line is constructed using one straightness profile, by fitting a least squares line or minimum zone pair of straight lines. A least squares straight line is then constructed from the second straightness profile.

The parallelism value is the difference in the separation of the datum line and the second least squares line over the length of the straightness profiles.



PAR (D) is defined as the peak to valley of the displacements of the test trace from the primary datum. i.e. Displacement of furthest data point from the primary datum, minus the displacement of the nearest point from the primary datum.

Summary

METEK*

- Instruments with vertical straightness units can be used to measure vertical straightness
 - If the instrument is fitted with a Radial Straightness Unit (RSU) horizontal straightness is also possible
- The choice of filter value will have quite a significant effect on the STRt value.
- When measuring straightness of narrow components it is difficult to keep the stylus on the crest of the part.
 - To prevent this phenomena a bar stylus can be used.
- By measuring two sides of a cylinder it is possible to find the parallelism of the cylinder.

Global Excellence in Metrology



Contact us

Material produced by Taylor Hobson Centre of Excellence For more information contact:

email: taylor-hobson.cofe@ametek.com

or call: +44 116 276 3779

Centre of Excellence Services

For calibration, training and precision metrology beyond the scope of your business expertise, the Taylor Hobson Centre of Excellence has experienced professional metrologists along with state of the art measuring instruments.

Metrology Training Courses

We offer standard and bespoke Training Courses in Surface Finish and Roundness, coupled with contact and noncontact Instrument Operator Training. To improve the understanding and application of Roundness and Surface Finish principles by your operators, inspectors and engineers.

Instrument Training

Without question, the benefits of training are exponentially greater than the cost. When your operators, inspectors and engineers are well versed in the theory and application of metrology they are more confident, more efficient, better informed and more likely to avoid mistakes or misrepresentation of results.

Technical Support

Manned by a team of Experienced Metrologist's, we provide a Case Study or Measurement Report Service alongside a Contract Measurement Service, to help in the correct selection of our metrology systems.

Global Excellence in Metrology



